

CLEANING GUIDE FOR 6900 PANINI PRESS

ROUTINE CLEANING



WIPE DOWN THE LOWER COOKING SURFACE AFTER EACH COOK CYCLE USING A DAMP NON-ABRASIVE CLOTH.



WIPE DOWN THE UPPER COOKING SURFACE, INCLUDING THE (2) WAVE GUIDE COVERS, AFTER EACH COOK CYCLE USING A DAMP NON-ABRASIVE CLOTH.

DAILY CLEANING



AT THE END OF EACH DAY, DROP THE UPPER HEATER PLATE ASSEMBLY FOR CLEANING. THIS CAN BE DONE BY TURNING THE RELEASE SHAFT ON TOP OF THE PRESS TO THE RELEASED POSITION. A TOWEL SHOULD BE PLACED ON THE LOWER HEATER PLATE BEFORE THE UPPER HEATER PLATE IS RELEASED TO PROHIBIT DAMAGE TO THE TEFLON COATING.

DAILY CLEANING CONTINUED...



USING A NON-ABRASIVE CLOTH WITH A MILD DETERGENT & WARM WATER, WIPE DOWN THE ENTIRE EXPOSED AREA OF THE UPPER CAVITY. THIS INCLUDES THE (2) WAVE GUIDE COVERS. ENSURE THAT ALL RESIDUAL FOOD AND DEBRIS ARE WIPED AWAY.



USING A NON-ABRASIVE CLOTH WITH A MILD DETERGENT & WARM WATER, WIPE DOWN THE TOP SIDE OF THE UPPER HEATER PLATE ASSEMBLY. ENSURE THAT ALL RESIDUAL FOOD AND DEBRIS ARE WIPED AWAY.



RE-INSTALL TOP HEATER PLATE ASSEMBLY INTO THE TOP CAVITY. INSERT THE POST INTO THE BUSHING IN THE TOP CAVITY AND TURN THE RELEASE SHAFT TO THE LOCKED POSITION.



USING A NON-ABRASIVE CLOTH WITH A MILD DETERGENT & WARM WATER, WIPE DOWN THE ENTIRE LOWER COOKING SURFACE, THIS INCLUDES THE AREA SURROUNDING THE HEATER PLATE. ENSURE THAT ALL RESIDUAL FOOD AND DEBRIS ARE WIPED AWAY.

DAILY CLEANING CONTINUED...



USING A NON-ABRASIVE CLOTH WITH A MILD DETERGENT & WARM WATER, WIPE DOWN THE ENTIRE UPPER COOKING SURFACE, THIS INCLUDES THE (2) WAVE GUIDE COVERS AND SURROUNDING SURFACES. ENSURE THAT ALL RESIDUAL FOOD AND DEBRIS ARE WIPED AWAY.



USING A NON-ABRASIVE CLOTH WITH A MILD DETERGENT & WARM WATER, WIPE DOWN THE ENTIRE OUTSIDE OF THE PRESS.

WEEKLY CLEANING




REMOVE BOTH AIR FILTERS LOCATED ON THE REAR OF THE PRESS.



USING A NON-ABRASIVE CLOTH & WARM WATER WIPE DOWN THE AREAS LOCATED BEHIND THE FILTERS. ENSURE THAT NEITHER OF THE FAN COVERS OR THE VENTS ARE BLOCKED BY DEBRIS - IT IS ESSENTIAL TO CORRECT OPERATION THEY ARE FREE & CLEAR.

WEEKLY CLEANING CONTINUED...



RINSE BOTH FILTERS USING WARM WATER. ENSURE THAT ALL DEBRIS IS REMOVED. IF DEBRIS IS TOO THICK TO BE REMOVED, REPLACE FILTERS BEFORE THE NEXT OPERATION. IT IS ESSENTIAL TO CORRECT OPERATION THAT THE FILTERS ARE CLEAN AND FREE OF ALL DEBRIS.

GENERAL NOTES

ROUTINE, DAILY, AND WEEKLY CLEANING ARE ESSENTIAL TO THE OPERATION AND FUNCTIONAL LIFE OF THIS PIECE OF EQUIPMENT. FAILURE TO FOLLOW THIS CLEANING GUIDE MAY RESULT IN REDUCED PERFORMANCE AND/OR FAILURE OF THE EQUIPMENT. FAILURE TO CLEAN THE TEFLON COATED PLATES AS RECOMMENDED WILL CAUSE REDUCED LIFE OF THEIR NON-STICK PROPERTIES AND WILL NOT BE COVERED UNDER WARRANTY.